


IES205G Unmanaged Industrial Ethernet Switch Quick Installation Guide



3onedata Co., Ltd.

Address: 3/B, Zone 1, Baiwangxin High Technology Industrial Park, Xili, Nanshan District, Shenzhen

Website: www.3onedata.com

Tel: +86 0755-26702688

Fax: +86 0755-26703485

【Package Checklist】

Please check whether the package and accessories are intact while using the switch for the first time.

- | | |
|---------------------------------|------------------|
| 1. Industrial Ethernet switch | 2. Certification |
| 3. Quick installation guide | 4. Warranty card |
| 5. DIN-Rail mounting attachment | |


If any of these items are damaged or lost, please contact our company or dealers, we will solve it ASAP.

【Product Overview】


The product is full Gigabit unmanaged DIN-Rail industrial Ethernet switch. Models as follows: IES205G (5 Gigabit copper ports).

【Panel Design】

➤ Rear view, Bottom view and Top view




➤ Front view and Side view



1. DIN-Rail mounting kit
2. Grounding screw
3. Power input terminal block
4. Ethernet port status indicator G1-G5
5. Power input status indicator PWR
6. 10/100/1000Base-T(X) Ethernet port

【Mounting Dimension】

Unit: mm




Attention before mounting:

- Don't place or install the device in area near water or moist, keep the relative humidity of the device surrounding between 5%~95% without condensation.
- Before power on, first confirm the supported power supply specification to avoid over-voltage damaging the device.
- The device surface temperature is high after running; please don't directly contact to avoid scalding.

【DIN-Rail Mounting】

For convenient usage in industrial environments, the product adopts 35mm DIN-Rail mounting, mounting steps as below:



- Step 1 Check whether the DIN-Rail mounting kit that comes with the device is installed firmly.
- Step 2 Insert the bottom of DIN-Rail mounting kit (one side with spring support) into DIN-Rail, and then insert the top into DIN-Rail.
- Tips:
Insert a little to the bottom, lift upward and then insert to the top.
- Step 3 Check and confirm the product is firmly installed on DIN-Rail, and then mounting ends.

【Disassembling DIN-Rail】

- Step 1 Power off the device.
- Step 2 After lift the device upward slightly, first shift out the top of DIN-Rail mounting kit, and then shift out the bottom of DIN-Rail, disassembling ends.




Attention before powering on:

- Power ON operation: first connect power line to the connection terminal of device power supply, and then power on.
- Power OFF operation: first unpin the power plug, and then remove the power line, please note the operation order above.

【Power Supply Connection】

➤ DC power supply



The product provides 3 pins power supply input terminal blocks with DC power input. The power supply supports nonpolarity and anti-reverse connection. It can normally operate after reverse connection. Power supply range: 12~48VDC. Pins definition of power supply as follows:

Pin NO.	1	2	3
Pins Definition	V-	FG	V+

【Checking LED Indicator】

The function of each LED is described in the table as below:

LED	Status	Description
PWR	ON	PWR is connected and running

Link/ ACT (G1- G5)		normally
	OFF	PWR is disconnected and running abnormally.
	ON	Ethernet port connection is active.
	Blinking	Data transmitted
	OFF	Ethernet port connection is inactive.

【Specification】

Panel	
Gigabit copper port	10/100/1000Base-T(X), flow control, full/half duplex, self-adapting operating mode, support MDI/MDI-X self-adaption, RJ45 port
Indicator	Power indicator, interface indicator
Exchange attributes	
Backplane bandwidth	14G
Packet buffer size	1Mbit
MAC table size	8K
Power supply	
Input power supply	12~48VDC Support nonpolarity and anti-reverse connection
Access terminal	3 pins 7.62mm pitch terminal blocks
Consumption	
No-load	0.86W @24VDC
Full-load	4.63W @24VDC
Environmental Limits	
Working temperature	-40~75℃
Storage temperature	-40~85℃
Working humidity	5%~95% (no condensation)
Protection grade	IP40 (metal shell)