


## NP5100 Series Safe Serial Server Quick Installation Guide



**3onedata Co., Ltd.**

Address: 3/B, Zone 1, Baiwangxin High Technology

Industrial Park, Xili, Nanshan District, Shenzhen

Website: [www.3onedata.com](http://www.3onedata.com)

Tel: +86 0755-26702688

Fax: +86 0755-26703485

### 【Package Checklist】

Please check whether the package and accessories are intact while using the serial server for the first time.

- |                             |                             |
|-----------------------------|-----------------------------|
| 1. Serial server            | 2. Quick installation guide |
| 3. Power line x2            | 4. Network cable            |
| 5. Rack-mounting lug x2     | 6. Foot pad x4              |
| 7. Software installation CD | 8. Warranty card            |
| 9. Certification            |                             |

If any of these items are damaged or lost, please contact our company or dealers, we will solve it ASAP.

### 【Product Overview】

The series products are managed rack-mounted industrial safe serial servers, including the following models:

Model I. NP5100-2T-32DI(3IN1)-RJ-OLED (2

10/100Base-T(X) copper ports + 32

RS-232/485/422 serial ports +1 OLED display)

Model II. NP5100-2T-32DI(3IN1)-RJ (2 10/100Base-T(X)

copper ports + 32 RS-232/485/422 serial ports)

Model III. NP5100-2T-16DI(3IN1)-RJ-OLED (2

10/100Base-T(X) copper ports + 16


RS-232/485/422 serial ports + 1 OLED display)

Model IV. NP5100-2T-16DI(3IN1)-RJ (2 10/100Base-T(X)


copper ports + 16 RS-232/485/422 serial ports)

### 【Panel Design】

#### ➤ Front View




Model I, Model II




Model III, Model IV


#### ➤ Rear View




Model I



Model II




Model III




Model IV

#### ➤ Top view



#### ➤ Left view and right view






1. RS-232/485/422 serial port
2. 100M Copper Port
3. Console port
4. DIP switch
5. Grounding screw
6. TF card slot
7. AC power input
8. Lugs
9. Serial port transmitting indicator
10. Serial port receiving indicator
11. Running indicator
12. Power indicator
13. Copper port connection indicator
14. OLED display
15. Menu/Exit button
16. Page UP
17. Page Down

18. Select/confirm button

## 【Mounting Dimension】

Unit: mm




### Note before mounting:

- Don't place or install the device in area near water or moist, keep the relative humidity of the device surrounding between 5%~95% without condensation.
- Before power on, first confirm the supported power supply specification to avoid over-voltage damaging the device.
- The device surface temperature is high after running; please don't directly contact to avoid scalding.


## 【Rack-mounted】

This product adopts rack-mounting, mounting steps as below:

- Step 1 Select the device mounting location to ensure enough size.
- Step 2 Adopt 4 bolts to install the mounting lugs in the device position as figure below.



Step 3 Place the device in the rack; adopt 4 bolts to fix two sides mounting lugs in the rack.



Step 4 Check and confirm the product is mounted firmly on the rack, mounting ends.

## 【Disassembling Device】

- Step 1 Device power off.
- Step 2 Adopt screw driver to loosen the 4 bolts fixed on the mounting lugs in the rack.
- Step 3 Shift out the device from rack, disassembling ends.



### Note before powering on:

- Power ON operation: First insert the power supply terminal block into the device power supply interface, and then plug the power supply plug contact and power on.
- Power switch “—” means power ON, “O” means power OFF.
- Power OFF operation: First, put the powers switch to the "O" side and then disconnect the power supply. Finally disconnect the connector between the device and the power cord. Please notice the operation order above.

## 【Power Supply Connection】


### ➤ AC power supply

This device provides 2 AC power supply access interfaces



which come with a switch.  
Voltage range: 85~265VAC.

## 【Serial Port Connection】



This device provides 3IN1 serial port, which supports RS232, RS485 and RS422 at the same time. The interface type is RJ45 and its pin definitions are as follows:

PIN	1	2	3	4	5	6	7	8
RS-232	DSR	RTS	GND	TXD	RXD	DCD	CTS	DTR
RS-485	—	—	GND	—	—	D-	—	D+
RS-422	—	R-	GND	R+	—	T-	—	T+

## 【DIP Switch Settings】



Provide 4 pins DIP switch for function settings, where "ON" is enable valid terminal. The device needs to be powered on again to change the status of DIP switch.

DIP switches definition as follows:

DIP	Definition	Operation
1	Reserved	-
2	Restore factory defaults	Set the DIP switch to ON, the device will root automatically and restore to factory settings, then turn off the DIP switch.
3	Reserved	-
4	Reserved	-

## 【Console Port Connection】

The series products provide 1 program debugging port based on RS-232 serial port which can conduct device CLI command management after connecting to PC. The interface adopts RJ45 port, the RJ45 pin definition as follows:

Pin No.	2	3	5
Definition	TXD	RXD	GND

## 【TF Card Slot】

This device provides 1 TF card slot. Using a screwdriver to unscrew the screw behind the TF card slot with slight strength and the card slot would pop up, then put TF card in the slot in the right way. TF card could be used for device upgrade. Before using it, please format the TF card into FAT32 format.



### Note:

In case of damaging TF card, user needs to power off the device first to change the TF card.

## 【Set OLED Display】

Model I and model III of the device provide liquid crystal display screens. Under normal working conditions, the liquid crystal display is dark and shows the IP address of LAN1. User can press the button to change the settings and query accordingly:

Key	Name	Command
MENU	Menu/Exit	Enter Main Menu/Back
⤴	Page UP	Select the last target
⤵	Page Down	Select the next target
SEL	Select/confirm	Select selected item

Display resolution is 128\*16, support numbers, English case, ".", "-", "\_", "↑", "↓" and other characters, support single line left and right scroll. Supports cursor blinking to determine the current cursor position. Trigger the button, the screen light is on. If there is no new operation for 30s, the screen would go into sleep state.

Detailed operation steps of OLED display screen are as follows:

Step 1 Start up, the first line shows the device name, the second line shows the LAN1 IP address.

SerialServer  
192.168.001.254

Step 2 Trigger the menu key to enter the menu interface,

options:

Main menu  
Server setting

- Server setting: basic information of the device, please skip to step 3 and step 6 for this setting;
- Network setting: network configuration, please skip to step 5 and step 6 for this setting;
- Save/Restart: Save Settings /Restart the device, skip to step 6 for this setting.

Step 3 Select Server setting on the Menu interface, trigger SEL key, enter the configuration interface of Server setting, options:

Server setting  
Serial number

- Serial number (read only);
- Server name (read only);
- Firmware ver (read only);
- Model name (read only);

Step 4 Select Network setting on the Menu interface, trigger SEL key, enter the configuration interface of Network setting, options:

Network setting  
LAN 1

- LAN 1: network card 1 configuration;
- LAN 2: network card 2 configuration.

Step 5 Select LAN 1(LAN 2) on the Network setting interface, trigger SEL key, enter the configuration

interface of LAN 1(LAN 2), options:

LAN 1  
Ethernet status

- Ethernet status: network card state (read only);
- MAC address: MAC address (read only);
- IP config: IP configuration method (trigger SEL key configuration)  
Options: Static, DHCP;
- IP address (read-write);
- Netmask (read-write);
- Gateway: default gateway (read-write).

Note:

When the configuration needs to be modified, it can be triggered by ^ and v keys to change the value.

Step 6 Select Save/Restart on the Menu interface, trigger SEL key, enter the configuration interface of Save/Restart, options:

Save/Restart  
Save

- Save: save configuration;
- Restart: reboot the device.

Note:

Select Save or Restart, the interface shows the Disable option (to prevent over-long key-press time and misoperation) first, it can trigger < button, select the Enable option, and then trigger the SEL button, Save the configuration or Restart the device.

## 【Checking LED Indicator】

The series products provide LED indicators to monitor the

device working status with a comprehensive simplified troubleshooting; the function of each LED is described in the table as below:

LED	Indicate	Description
POWER (1-2)	ON	PWR is connected and running normally
	OFF	PWR is disconnected and running abnormally
RUN	Blinking	System runs normally
	OFF	The system is not running or running abnormally
	ON	System is running abnormally
Link(1-2)	ON	Port has established valid network connection
	Blinking	Port is in a network communication status
	OFF	Port hasn't established valid network connection.
TX(1-32)	OFF	No data or abnormal data is being transmitted through serial port.
	Blinking	Serial port is transmitting data.
RX(1-32)	OFF	Serial port is not receiving data or receiving data abnormally
	Blinking	Serial port is receiving data.

### 【Logging in to WEB Interface】

This device supports WEB management and configuration. Computer can access the device via Ethernet interface. The way of logging in to device's configuration interface via IE browser is shown as below:

Step 1 Configure the IP addresses of computer and the device to the same network segment(The network segment of Network Port 1 is 1, and the network segment of network port 2 is 8), and the network between them can be mutually

accessed.

Step 2 Enter device's IP address in the address bar of the computer browser.

Network Port 1:

Network Port 2:

Step 3 Enter device's username and password in the login window as shown below.



Step 4 Click "OK" button to login to the WEB interface of the device.



#### Note:

- The default IP address of the device Network port 1 is "192.168.1.254", the default IP address of the network port 2 is "192.168.8.254".
- The default user name and password of the device are "admin".
- If the username or password is lost, user can restore it to factory settings via device DIP switch or management software; all modified configurations will be cleared after restoring to factory settings, so please backup configuration file in advance.

- Please refer to user manual for specific configuration method of logging in to WEB interface and other configurations about network management function.

### 【Specification】

Panel	
100M Copper Port	10/100Base-T(X) self-adapting RJ45 port, half/full duplex self-adapting or forced working mode, support MDI/MDI-X self-adapting
Serial Port	3IN1 serial port, adopts RJ45, supports 15KV ESD protection
Console port	CLI command management port (RS-232), RJ45
Indicator	Power indicator, running status indicator, copper port connection status indicator, serial port receiving indicator, serial port transmission indicator
OLED display	Menu/Exit, page up, page down, select/confirm
Power Supply	
Input power supply	85~265VAC
Access terminal block	Support single-phase socket with rocker switch
Power Consumption	
No-load	5.6W@220VAC
Full-load	13.2W@220VAC
Working Environment	
Working temperature	-40~75℃
Storage temperature	-40~85℃
Working humidity	5%~95% (no condensation)
Protection grade	IP40 (metal shell)